

Versión 1.0

- Primera versión.

Versión 2.0

- Versión compatible con apertura bluetooth.
Requiere la adquisición de las licencias específicas de uso y una versión de Z-Access a partir de 3.0.17.
- Novedades funcionales:
 - Cuando se lee una tarjeta y se concede el acceso se envía al bus un objeto con el idioma de la tarjeta leída.
 - Objeto para inhabilitar el estado limpiar
 - Envío de diferentes escenas de bienvenida en función de quien acceda a la estancia:
 - Primer acceso. El dispositivo de lectura (IWAC/IDAC) será capaz de saber si es la primera vez que se accede a la habitación para enviar una escena de bienvenida diferente a las sucesivas
 - Escenas distintas para grupos/huéspedes.
 - Se añaden nuevos mensajes en el display para saber cuándo la habitación está ocupada y cuando está ocupada y además el huésped ha seleccionado no molestar.
 - Salvado de accesos durante fallo de bus: se permitirá almacenar en la memoria de salvado los datos de hasta 10 intentos de acceso durante fallo de bus para ser enviados cuando el bus sea recuperado. Estos valores permanecerán incluso ante un fallo de alimentación.
Este envío de datos se hace por objetos de interfaz (properties)

Version 1.0

- Initial version.

Version 2.0

- Version compatible with bluetooth door opening.
It requires the acquisition of a specific license and Z-Access version 3.0.17 or higher.
- Functionality novelties:
 - When a card is read and access is granted the language of the card is sent to the bus
 - There is a new object to enable/disable the "Make Up Room" state.
 - Possibility to send different scenes depending on who and when is accessing the room:
 - First access: The Zennio Access Device (IWAC/IDAC) will be able to identify if it is the first time the guest access the room after a checkin to send a different scene than the one which is sent when the guest enters afterwards.
 - Different scenes for groups and guests.
 - New messages are added in the display to check when the room is occupied and also when the room is occupied and the guest has selected Do Not Disturb.
 - Access data log is saved in case of bus failure.
Information of up to 10 access during bus failure is recorded and sent to the Z-Access once the bus is recover. This sending is done using properties.